

Suggested Settings

Configuraciones que sugerimos • Soundvorschläge • Exemples de Réglages • 設定例

Full Bodied Clean

AMP 1 control panel for Full Bodied Clean. Includes buttons for CLEAN, CRUNCH, and AMP 1. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.

Solid Rhythm

AMP 2 control panel for Solid Rhythm. Includes buttons for AMP 2 and 001. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, TONE MATRIX, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.

'Plexi' Clean

AMP 1 control panel for 'Plexi' Clean. Includes buttons for CLEAN, CRUNCH, and AMP 1. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'IN' label.

Classic Metal

AMP 2 control panel for Classic Metal. Includes buttons for AMP 2 and 001. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, TONE MATRIX, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.

Dynamic Blues Solo

AMP 1 control panel for Dynamic Blues Solo. Includes buttons for CLEAN, CRUNCH, and AMP 1. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.

Detuned

AMP 2 control panel for Detuned. Includes buttons for AMP 2 and 001. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, TONE MATRIX, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'IN' label.

Hotrodded JCM800

AMP 1 control panel for Hotrodded JCM800. Includes buttons for CLEAN, CRUNCH, and AMP 1. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.

Extreme Detuned

AMP 2 control panel for Extreme Detuned. Includes buttons for AMP 2 and 001. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, TONE MATRIX, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'IN' label.

Extreme Thrash

AMP 1 control panel for Extreme Thrash. Includes buttons for CLEAN, CRUNCH, and AMP 1. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'IN' label.

Smooth Shred

AMP 2 control panel for Smooth Shred. Includes buttons for AMP 2 and 001. Knobs for GAIN, VOLUME, REVERB, FX LEVEL, TONE MATRIX, BASS, MIDDLE, TREBLE, and SCOOP. A central MODEFOUR logo is present. Below the panel is an 'OUT' label.